



### **Low flame, low temperature?**

These have become the biggest problems with many grills recently and are almost always because of the regulator (the funny UFO shaped thing on the gas hose). Regulators seem to be stickier these days and when they stick you won't get enough gas to generate a good grilling temperature. To reverse this, you need to release the pressure on the regulator.

Follow these steps:

1. Turn off the gas at the propane tank
2. Disconnect the gas line from the tank
3. Open the grill lid
4. Turn all control valves to high
5. Wait for about a minute
6. Turn all control valves to off
7. Reconnect the gas line to the tank
8. SLOWLY turn on the gas at the tank
9. Light the grill normally
10. Your grill should now heat normally

To keep the regulator from sticking again, make sure to turn off the control valves first, then turn off the tank valve. Always open the tank valve slowly.

If this doesn't work give it a second try. If you still have low flame, then you probably have a faulty regulator that will need to be replaced. Please contact the Wardway Grill Gurus - 513-574-0061 -with any questions.